

正面 双面印刷, 风琴叶折叠 单页110*110mm

PentaWave
QUICK INSTALLATION GUIDE
Z05C

2024-J

ACCESSORIES

A HEATSINK *FAN PRE-INSTALLED	B COMPOUND	C INTEL BP
F BLACK SPACER 10.8mm AM5	G NICKEL M3 INTEL SC	H BROWN SPACER 9.8mm INTEL/AM4
D BRACKET	E FAN CLIP	I BLACK NICKEL 6-32 AMD SC

x1 x1 x1 x1 x2 x4 x4 x4 x4

INTEL 1200/1700/1851

1 INTEL 1700/1851
INTEL 115X/1200

2

3 INTEL 1700/1851
INTEL 115X/1200

4

AMD AM4

1 REMOVE AMD BRACKET FROM MB

2

3 ROTATE 90° INSTALL

4

AMD AM5

1 REMOVE AMD BRACKET FROM MB

2

3 ROTATE 90° INSTALL

4

HEATSINK INSTALLATION

1

2

CABLE INSTALLATION

INSERT THE PWM CONNECTOR INTO THE MB ARGB/D-RGB PORT

INSERT THE ARGB CONNECTOR INTO THE MB ARGB/D-RGB PORT

*OPTIONAL

PentaWave
快速安装指引
Z05C

2024-J

配件清单

A 散热器 *已预装风扇	B 导热膏	C INTEL 背板
F 黑色AM5垫柱 10.8mm	G 镀镍 M3 INTEL 螺丝	H 棕色垫柱 9.8mm INTEL/AM4
D 扣具支架	E 风扇扣条	I 镀镍黑 6-32 AMD 螺丝

x1 x1 x1 x1 x2 x4 x4 x4 x4

INTEL 1200/1700/1851

1 INTEL 1700/1851
INTEL 115X/1200

2

3 INTEL 1700/1851
INTEL 115X/1200

4

AMD AM4

1 将原装AMD的散热器扣具移除, 保留背板

2

3 支持旋转90度安装

4

AMD AM5

1 将原装AMD的散热器扣具移除, 保留背板

2

3 支持旋转90度安装

4

HEATSINK INSTALLATION

1

2

CABLE INSTALLATION

INSERT THE PWM CONNECTOR INTO THE MB ARGB/D-RGB PORT

INSERT THE ARGB CONNECTOR INTO THE MB ARGB/D-RGB PORT

*OPTIONAL